



B TYPE, BH TYPE

MOUNTING HOLE DIMENSIONS

		B	B-SN, SM	B-HC, TC, FC, SC	B-KMC	BL
B TYPE	H.T	Manual return				
	S	Automatic return				
	SB	Pushing and pulling				
	SQ	Dual body type				
	W	Lockout relay				
	Mounting screw	M5×12 countersunk screws: 2	M5×12 countersunk screws: 2	M5×12 countersunk screws: 2	M4×12 countersunk screws: 2	M5×10 countersunk screws: 2
		B-KM	B-KH		BM	
	Key: right		Key: bottom		Key: right	
	Key: bottom		Key: right		H.T	Manual return
					S	Automatic return
					SB	Pushing
	Mounting screw	M5×12 countersunk screws: 2	M5×10 countersunk screws: 2	M5×12 countersunk screws: 2	M5×10 pan head screws: 2	M5×12 countersunk screws: 2

		BH	BHK	BHO	BHC	
BH TYPE	H.T	Manual return			Key: bottom	
	S	Automatic return			Key: right	
	SB	Pushing and pulling				
	SQ	Dual body type				
	BHE	Lockout relay				
	Mounting screw	M5×10 countersunk screws: 2	M5×12 countersunk screws: 2	M4×12 countersunk screws: 2	M5×10 countersunk screws: 2	
		BHP	BHI	BHS, BHSB	BHM	
	Key: bottom		Key: right		H.T	Manual return
					S	Automatic return
					SB	Pushing
	Mounting screw	M5×10 countersunk screws: 2	M5×10 countersunk screws: 2	M5×12 countersunk screws: 2	M5×10 pan head screws: 2	M5×10 countersunk screws: 2