



FEATURES

This micro drum switch is compact and highly functional with high reliability. The control switch has critical roles among the control devices that constitute the core of the neural system of a plant. The micro drum switch ensures stable reliability in emergency as well as in normal use. In addition, it effectively utilizes the panel surface as the interface for the control devices, and plays great roles for improving the panel design.

■Sliding contact method

The sliding contact method has been adopted to ensure high contact reliability. In this method, the contacting

surfaces of the contactors rub each other so that dust and other foreign matter can be cleaned completely.

■High density of mounting

LED indicators are mounted in the nameplate part. This design further improves the density of mounting on the panel (ML type).

Correspond to various power sources

The power source for indicators is selectable from 110 and 220V AC, 24, 48, 110, and 125V DC. This variety of options allows for complying with different needs.

SPECIFICATIONS (RATINGS, PERFORMANCE)

Specification	M TYPE, ML TYPE
Rated insulation voltage (Ui)	250V
Rated current-carrying capacity (Ith)	8A
Max. wire size	5.5mm²
Screw size	M4×8
Withstand voltage	2,500V AC / 1 min.
Lightning impulse	±7kV 1.2 / 50µs
Contact resistance	50mΩ or less
Mechanical life	50,000 operations or more, Class 5
Electrical life	10,000 operations or more, Class 5
Shock resistance	294m/s²
Vibration resistance	Acceleration: 50Hz, 20 m/s², Time: 2 hours (3 directions)
Operating temperature	−20 to 50°C
Storing temperature	−40 to 70°C
Altitude	2,000 m or less

■Breaking capacity [electrical life of 10,000 operations (class 5)]

	AC			DC						
Rated voltage (V)	Rated operating current (resistance load) (A)	Rated operating current (inductive load) (A)	Rated voltage (V)	Rated operating current (resistance load) (A)	Rated operating current (inductive load) (A)	2 contacts used in series Rated operating current (resistance load) (A)				
110	8	8								
220	5	4	48	8	8	8	8			
			110	3	2	3	3			
			220	1	0.7	1	1			

* Inductive load: For AC: Power factor 0.6 to 0.7 (Class: AC11) , For DC: Time constant 40±6ms (Class: DC12)

HOW TO ORDER

Circuit No. (arrangement) Please see page

When indicators are provided: LED display circuit type

A96 standard arrangement diagram.

<u>M-H 4-2B2A-SD-B 1151-F MA-000</u>

(1)	2 3 4	(5) (4) (5)	6 7	8 9 10 11 1	2) (13)
No.	Item	Code	De	tail	Note
		М	M type switc	h (basic type)	
		ML		with indicator	
1	Basic type	M-KH	M type switch with	Page A94 to 95	
		ML-KH	M type switch with indicat	or and padlock mechan	ism
		M-KMC	M type switch (k		
2	Notch code		Please see page A92 for I	Page A92	
3	No. of units	1-8	Max. 8 units	* In the case of T C circuit, 1 unit is required for wiring.	
4	No. of contacts				_
(5)	Contact code		Please see page A93 for C	Page A93	
6	Handle code	Pistol sh	ape:SP Rose shape:SD	Octagonal shape:SF	Page A93
			Munsell color co		
(7)	Handle color		Handle	Flange	
0	Hariule Color	В	N1.5	N1.5	_
		BG	7.5BG3 / 3.5	7.5BG4 / 1.5	
		1	H (for 2 indicators)	For DC	
		2	Y (for 2 indicators)	For DC	
		3	H.Y (for 2 indicators)	For AC	* For special specifications,
8	Circuit	4	S (for 1 indicators)	For AC / DC	please make enquiry to
		5	T.C (for 3 indicators)	Fuji Electric Industry.	
		6	Y (P-common for 2 indicators)		
		9	Special		
		1	24\	/ DC	
		2	48\	/ DC	
		3	100 / 1	10V DC	* For special specifications,
9	Voltage	4		10V AC	please make enquiry to
		5	200 / 2	20V AC	Fuji Electric Industry.
		6	125	V DC	
		9	Spe	ecial	
		1	W (V	Vhite)	
		2	R (I	Red)	
		3	G (G	reen)	
(10)	Display color	4	O (A	mber)	* For special specifications,
10	Display Color	5		iR .	please make enquiry to
		6	G ¹	WR	Fuji Electric Industry.
		7	G		
		9		ecial	
		1		1.5	
11)	Frame color	2		В	
		9		ecial	
(12)	Terminal specification	No code		rew	_
	i i	F		ston tab	
(13)	Nameplate		Please select a namep	late No.	Page A102

■Notch code

Code	Н	Т	F	S	SB
Notch configuration	В А	B A T	A T F	B C A	
Operation	(90°-2) 2 notches	(45°-3) 3 notches	(45°-4) 4 notches	(45°-3) 3 notches	Automatic rotating return
·		Manual return		Automatic return	Automatic axial return

(Note) In the above table, the ● mark indicates the ordinary stop position of the switch. The → mark shows that the switch moves in this direction and then automatically stops in the arrowhead position.



DRUM SWITCH

M TYPE, ML TYPE


■Contact code

Code	Graphic symbol	Туре	Description	Code	Graphic symbol	Туре	Description
В	+ +	Normal	Making at the B position <45°>	(B)L	+++		Shows for overlap contact. To be added to the standard contact symbol (B to F).
Α	++	contact	Making at the A position <45°>	М	+++		Contacts close between left and center positions.
т	+++	Normal	Making at the T position <45°>	N	+++		Contacts close between right and center positions.
F	++++	contact	Making at the F position <45°>				_

■ Handle code

Code	SP	SD	SF
Shape	Pistol shape	Rose shape	Octagonal shape

■LED display circuit type



■ML type lamp circuit R: Limit resistor D: Rectifying diode LED: LED element


_	1 lamp	2 lamps	2 lamps	2 lamps, P common	
ran	S circuit (DC circuit)	H circuit (DC circuit)	Y circuit (DC circuit)	Y circuit (DC circuit)	
Lamp circuit diagram	© COM R. COM	© R COM	© R SLED COM	3 o R DED COM	
_	3 lamps	1 lamp	2 lamps	3 lamps	
circuit diagram	3 lamps T.C circuit (DC circuit)	1 lamp S circuit (AC circuit)	2 lamps H.Y circuit (AC circuit)	3 lamps T.C circuit (AC circuit)	

OUTLINES M TYPE

Automatic return and manual return type

M-S,H,T,F








No. of units	1	2	3	4	5	6	7	8
L (mm)	31	41	51	61	71	81	91	101

Automatic return type by pulling

M-SR









N	No. of units	1	2	3	4	5	6	7	8
	L (mm)	58.5	68.5	78.5	88.5	98.5	108.5	118.5	128.5

Automatic return and manual return type (with padlock mechanism)


M-KH-S,H,T,F

Key lock position

₩ NUKI C	NUKI BA NUKI B NUKI A	NUKI BAT	NUKI BATF
S	Н	Т	F











- ORemove the padlock and push the lock release lever, then allows you to operate the switch. After finishing the operation, if you release your finger, the switch will be locked automatically.
- * Padlock size: 5 mm.

No. of units	1	2	3	4	5	6	7	8
L (mm)	58.5	68.5	78.5	88.5	98.5	108.5	118.5	128.5

Key-operated type: Automatic return type and manual return type

M-KMC-S,H,T,F

Key lock position




S H

NUKI A NUKI A

T F











The figure shows the switch with the C-88MS type cylinder lock. There are no
more than 10 kinds of keys available and no master key is supplied. In case of
the key type C110, there are more than 10 kinds of keys available and the
master key comes with the switch, the L dimension of the switch becomes
longer by 5 mm. Please see page A14 for key system and specify the key No.


No. of units	1	2	3	4	5	6	7	8
A (mm)	31	41	51	61	71	81	91	101
L (mm)	66	76	86	96	106	116	126	136


OUTLINES ML TYPE


* If the LED lamp circuit is T or C, it's necessary to attach an unit for wiring to the switch body.

Automatic return type and manual return type with indicators

ML-S,H,T,F










* In the case of T C circuit, 1 unit is required for

Automatic return type by pulling











L (mm) * In the case of T C circuit, 1 unit is required for wiring.


2


Automatic return type and manual return type with padlock mechanism













No. of units	1	2	3	4	5	6	7	8
L (mm)	58.5	68.5	78.5	88.5	98.5	108.5	118.5	128.5

STANDARD ARRANGEMENT DIAGRAM

a) For voltmeter (standard handle: SD)



b) For ammeter (standard handle: SD)






(S)

(SB)

STANDARD ARRANGEMENT DIAGRAM

■Automatic return type and pulling type (S) (SB)

•2 contacts (2 units)



•3 contacts (3 units)

Type (automatic return)	S3001M	S3002M	S3003M	S3004M	S3005M	S3006M
Detail	S3-1C1B1A	S3-1B2A	S3-1M1N1A	S3-1N1B1A	S3-1N2A	S3-2N1B
Contact arrangement	5 6 4 3 4 1 B C A	5 6 3 4 1 2 B C A	5 6 4 1 2 B C A	5 6 4 1 1 1 2 B C A	5 6 3 4 1 2 B C A	5 6 3 4 0 2 B C A
Type (pulling)	SB3001M	SB3002M	SB3003M	SB3004M	SB3005M	SB3006M

•4 contacts (4 units)

Type (automatic return)	S4001M	S4002M	S4003M	S4004M	S4005M	S4006M
Detail	S4-1C1B2A	S4-2C1B1A	S4-2B2A	S4-1N1B2A	S4-1N1C1B1A	S4-1M1N1B1A
Contact arrangement	7 8 5 6 3 4 0 2	7 - 8 6 3 - 4 2 B C A	7 8 6 8 3 4 0 2 B C A	(5) (8) (8) (8) (9) (9) (9) (9) (9) (9) (9) (9) (9) (9	(5) (8) (8) (8) (8) (8) (8) (8) (8) (8) (8	8 6 3 C A
Type (pulling)	SB4001M	SB4002M	SB4003M	SB4004M	SB4005M	SB4006M
Type (automatic return)	S4007M	S4008M	S4009M	S4010M	S4011M	S4101M
Detail	04.4844804	S4-2N1B1A	S4-2N2B	S4-2N2A	S4-2M2N	S4-2 (1A1B)
	S4-1M1N2A	34-2N1D1A	34-51V2D	54-2N2A	34-ZIVIZIN	54-2 (TATB)
Contact arrangement	\$4-1M1N2A 7 8 6 6 3 4 1 2 B C A	7 8 6 3 4 4 1 2 B C A	7 8 6 3 4 1 2 B C A	\$4-2N2A \$\begin{array}{cccccccccccccccccccccccccccccccccccc	34-2W2N	3 4 4 1 B C A

●6 contacts (6 units)

• conta	icis (6 units)					
Type (automatic return)	S6001M	S6002M	S6003M	S6004M	S6005M	S6006M
Detail	S6-3B3A	S6-2B4A	S6-4B2A	S6-2C1B3A	S6-2C2B2A	S6-2N2B2A
Contact arrangement	10 12 9 10 7 8 5 6 3 4 1 2 B C A	1)	11	0 - 2 9 - 0 7 - 8 5 - 6 3 - 4 1 - 2	1) - 2 9 - 10 7 - 8 5 - 6 3 - 4 1 - 2 B C A	11
Type (pulling)	SB6001M	SB6002M	SB6003M	SB6004M	SB6005M	SB6006M
Type (automatic return)	S6007M	S6008M	S6009M			
Detail	S6-2N4A	S6-3N3A	S6-1M1N2B2A			
	10 + 12	0 12	10 12			



(automatic return)	S8001M	S8002M	S8003M	
Detail	S8-4B4A	S8-2N2B4A	S8-2M2N2B2A	
Contact arrangement	6 6 6 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9	(5) - 6 (3) - 19 (1) - 10 (2) - 8 (5) - 6 (3) - 4 (1) - 2 (2) B C A	(5) (6) (3) - (9) (10) (10) (2) (3) (4) (4) (4) (4) (4) (4) (4) (4) (4) (4	
Type (pulling)	SB8001M	SB8002M	SB8003M	

■90° 2-position changeover (H) •2 contacts (2 units) ●1 contact (1 unit)

Type	H1001M	H1002M
Detail	H1-1A	H1-1B
Contact arrangement	①	① + 2 B A

	H2001M H2002M		H2003M	H2004M
]	H2-2A	H2-2B	H2-1B1A	H2-1BL1AL
	3 4 4 2 B A	3 4 4 1 B A	3 4 4 1 B A	3 4 2 B A

●3 contacts (3 units)

Туре	H3001M	H3002M	H3003M	H3004M	H3005M
Detail	H3-3A	H3-3B	H3-1B2A	H3-2B1A	H3-1B2BL
Contact arrangement	(5) (6) (3) (4) (1) (2) (B) A	5 + 6 3 + 4 1 + 2 B A	(5)	5 6 6 3 4 1 2 B A	5 6 6 3 4 0 D B A

•4 contacts (4 units)

Туре	H4001M	H4002M	H4003M	H4004M	H4005M	H4006M
Detail	H4-4A	H4-4B	H4-1B3A	H4-3B1A	H4-2B2A	H4-1B1A1BL1AL
Contact arrangement	7 8 6 6 3 4 1 B A	7 + 8 5 - 6 3 - 4 1 - 2 B A	7 8 6 3 4 1 4 2 B A	7 8 6 6 3 4 1 2 B A	7 8 6 3 4 0 D B A	7 8 6 6 3 4 0 B A

Туре	H4007M	H4008M	H4102M
Detail	H4-2BL2AL	H4-1BL3AL	H4-2AL2B
Contact arrangement	7 8 6 6 3 4 1 2 B A	7 8 6 5 6 3 4 1 2 B A	7 8 6 6 3 4 4 2 B A



STANDARD DEVELOPMENT DIAGRAM

■90° 2-position changeover (H)



•6 contacts (6 units)

Туре	H6001M	H6002M	H6003M	H6004M	H6005M
Detail	H6-6A	H6-6B	H6-3B3A	H6-1B5A	H6-2B4A
Contact arrangement	1)	10 - 2 9 - 10 7 - 8 5 - 6 3 - 4 1 - 2 B A	10	10	10
Туре	H6006M	H6007M	H6008M	H6009M]
Detail	H6-4B2A	H6-5B1A	H6-2BL4AL	H6-3BL3AL	
Contact arrangement	1)	1)	10 - 12 9 - 10 7 - 8 5 - 6 3 - 4	1)	

Å

●8 contacts (8 units)

Туре	H8001M	H8002M	H8003M	H8004M	H8005M
Detail	H8-8A	H8-1B7A	H8-2B6A	H8-3B5A	H8-4B4A
Contact arrangement	15	(5)	(5) - (6) (8) (10) (10) (10) (10) (10) (10) (10) (10	(5)	(5) - (6) (13 - (14) (15) (15) (15) (15) (15) (15) (15) (15
Туре	H8006M	H8007M	H8008M	H8101M]
Detail	H8-5B3A	H8-6B2A	H8-4BL4AL	H8-4A4B	
	(5) - (6) (3) - (4) (1) - (2)	(5) - (6) (3) - (4) (1) - (2)	(5)————————————————————————————————————	15 16 13 14 10 12	

■45° 3-position changeover (T)



●2 contacts (2 units)

Contact arrangement

			•			
Туре	T2001M	T2002M	T2003M	T2004M	T2101M	
Detail	T2-1A1T	T2-1B1A	T2-1B1T	T2-1BA1AT	T2-1AT1T	
Contact arrangement	3 4 4 2 B A T	3 4 4 Q D A T	3 4 4 1 2 B A T	3 4 4 1 2 B A T	3 4 4 1 2 B A T	

■45° 3-position changeover (T)



●3 contacts (3 units)

Type	T3001M	T3001M T3002M		T3004M	T3005M	T3006M	
Detail	T3-1A2T	T3-1B1A1T	T3-1BL1AL1TL	T3-1B2A	T3-2B1A	T3-1B1T1AT	
Contact arrangement	5 6 3 4 1 2 B A T	5 6 4 3 4 0 2 B A T	5 6 3 4 0 2 B A T	5 6 3 4 0 1 2 B A T	5 6 3 4 0 1 2 B A T	5 6 3 4 0 2 B A T	

•4 contacts (4 units)

Туре	T4001M	T4002M	T4003M	T4004M	T4005M	
Detail	T4-2A2T	T4-2B2A	T4-1B1A2T	T4-1B2A1T	T4-2B2T	
Contact arrangement B A T		7 8 8 6 3 4 1 2 B A T	7	7 4 8 6 6 3 4 1 2 B A T	7 8 6 3 4 1 2 B A T	
Туре	T4006M	T4007M	T4008M	T4009M	T4010M	
Type Detail	T4006M T4-2B1A1T	T4007M T4-3B1T	T4008M T4-1B1A1T1BA	T4009M T4-1A1T2AT	T4010M T4-1BL1AL2TL	

●6 contacts (6 units)

Contact arrangement

Туре	T6001M	T6002M	T6003M	T6004M	T6005M	
Detail	T6-2A4T	T6-1B1A4T	T6-1B3A2T	T6-1B4A1T	T6-2B2A2T	
Contact arrangement	11	10	10 + 12 9 - 10 7 - 8 6 - 6 3 - 4 10 + 2 B A T	10	10	
Туре	T6006M	T6007M	T6008M	T6009M	T6010M	
Detail	T6-2B4T	T6-2B4A	T6-2B1A3T	T6-3B3A	T6-3B3T	
Contact arrangement	10 12 10 10 10 10 10 10 10 10 10 10 10 10 10	10	11 12 10 10 7 8 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6	10	11	
Туре	T6011M	T6012M				
Detail	T6-2A2T2AT	T6-2BL2AL2TL				
Detail	16-2A212A1	10-2DL2AL21L				



M TYPE, ML TYPE

STANDARD ARRANGEMENT DIAGRAM

■45° 4-position changeover (F)

T A A5 - 45. F

•4 contacts (4 units)

Туре	F3001M	F3001M F3002M		F4002M	F4003M	
Detail	F3-1A1T1F	F3-1F1TF1ATF	F4-1B1A1T1F	F4-1A1T2F	F4-1A2T1F	
Contact arrangement	5 6 3 4 4 1 B A T F	(5) (6) (3) (4) (2) (2) (B) A T F	7 8 6 6 3 4 7 F	7 8 6 6 3 4 7 F	7 8 6 6 3 4 7 F	

•6 contacts (6 units)

●3 contacts (3 units)

Туре	F6001M	F6001M F6002M		F6004M	
Detail	F6-2A2T2F	F6-2B2T2F	F6-2B1A1T2F	F6-2B2A1T1F	
Contact arrangement	10 12 9 10 7 8 6 6 3 4 4 1 F	10 12 12 10 7 10 7 10 10 10 10 10 10 10 10 10 10 10 10 10	10 12 10 10 7 10 10 10 10 10 10 10 10 10 10 10 10 10	9 10 10 7 8 6 6 4 0 0 10 10 10 10 10 10 10 10 10 10 10 10	

●8 contacts (8 units)

Туре	F8001M	F8002M	F8003M	
Detail	F8-2B2A2T2F	F8-2A2T4F	F8-3B2T3F	
Contact arrangement	(5) (6) (7) (8) (7) (8) (8) (7) (8) (8) (8) (8) (8) (8) (8) (8) (8) (8	(5 16 17 17 17 17 17 17 17	15	


ACCESSORIES

Jumper (selling separately)



For adjacent terminals

●MS Jumper B



For skipping one terminal

MS Jumper C

For skipping two terminals

Handle



$\overline{}$	- <i>-</i>	Т	
Code	Shape		
SP	Pistol shape	C	ode
SD	Rose shape		В
SF	Octagonal shape	E	3G


de Color 3 N1.5 G 7.5BG3/3.5

Please check a dimensions from page A93.

ACCESSORIES

ML LED pack

ML-2352





Handle cap remover (selling separately)

M remover

A




* For circuits, see the specification of the LED display part circuit on page A93.

Nameplate

Material......Aluminum

LetterRound Gothic



(For 2 notches)

Nameplate No.	E	3	ı	4	N
MA-000				Plai	n
MA-200	ţ	ŋ	7	(
MA-201	手	動	自	動	
MA-202	単	独	連	動	
MA-209	停	止	運	転	
MA-211	現	場	電気	1 室	
MA-212	電気	主室	中	央	
MA-251	ţ	Ŋ	7	(しゃ断器
MA-252	ţ			(操作スイッチ
MA-253	手	動	自	動	切換スイッチ
MA-270	不够	き 用	使	用	切換スイッチ
MA-277	B	FI .	19	1	
MA-278	現	場	中	央	
MA-279	No	.1	No	.2	
MA-292	ţ	Ŋ	7	(しゃ断器テスト
MA-293	現	場	中	操	操作切換器
MA-227E	OP	EN	CLC	DSE	
MA-281E	OF	F	0	N	CIRCUIT BREAKER
MA-282E	LOC	CAL	REM	OTE	CONTROL
MA-1201E	OF	F	0	N	AUTO RECLOSING




Nameplate No.		В		M		Α		N		
MA-290	T	ţ	ŋ	交流しゃ断	器		入			_
MA-291	Π	ţ	IJ	線路開閉器	-		入			
MA-292	Т	ţ	IJ	しゃ断器テス	۲		入			_
MA-293		現	場	操作切換器	}	中		操		



В

Nameplate No. В Α N MA-300 停止 開 LOCAL REMOTE CONTROL MA-376E OFF



(For 4 notches)

Nameplate No.	В	Α	Т	F	N
MA-452	0	R	S	Т	電圧計
MA-453	0	R-S	S-T	T-R	電圧計
MA-455	0	R	S	T	電流計
MA-464	0	R-N	N-T	T-R	電圧計
MA-1401(E)	OFF	R	Υ	В	AMMETER

TYPE, ML TYPE

3 After removing the

cover, remove the screw.

HOW TO REMOVE

(1) How to remove the handle



There are three types of M/ML type handles as described above. The removal procedure is the same for all three types, so we will use the SP handle here.



The first step is to remove the handle cover

- ①Hook a tool or a flat-blade screwdriver into the concave portion of the handle.
- (toward this side) to remove it.

* The following is ML type.



(4) The handle can also be removed by removing the screw. *Once removed, the handle cannot be installed. Please install a new set of handles

②Apply force in the direction of the arrow

(2) How to remove the nameplate



5 Hook a tool or a flat-blade screwdriver into the concave portion of the handle. ⑥Apply force in the direction of the arrow (toward this side) to remove it.

(3) How to remove the flange



Remove the two point screws with a Phillips screwdriver.



®Caution

After removing the screws, the flange and the switch body will come off the panel, so please have two people working on the switch, one inside the panel and one outside the panel.

(4) Completion




REPRESENTATION OF ARRANGEMENT DIAGRAM

1 Graphic symbol

Action of contact	Symbol		
Normal making contact	•		
Close keep contact	←•		
Continuous closing contact	•—•		
Over-lapping contact	+4		

	Operation	Symbol		
ĺ	Manual return (rotating direction)	Not indicated		
	Manual return (axial direction)	•—•		
	Automatic return (return direction)	===		
	Automatic return (axial direction)	•——		


2 Representation method for contact arrangement



The development is diagrammatically represented as follows. For further details, see "3 Example of diagrammatical representation of development".

- 1. Denote a terminal with \bigcirc and enter its number in that circle.
- 2. The extent of the development figure is defined by a solid-line frame.
 - 3. An operation position is shown with a vertical thin line between terminals.
- 4. An operation position name is shown on the handle in the development figure.5. The contact symbol in the above . which is shown on the thin line showing
- In econtact symbol in the above 1, which is shown on the thin line showing the operation position, indicates that the mutually opposite terminals in that position are closed.
- 6. The function symbols showing the operation direction and the return position are shown on the handle in the development figure.
- 7. The handle of the switch is shown in the lower position of the figure.

3 Example of diagrammatic representation of development



The figure shows the switch that is designed to stop in the switching position. More specifically, when the switch is set to the AUTO position, the circuit between terminals 3 and 4 is closed and that between terminals 1 and 2 opened. When the switch is set to the MANU. position, opening and closing are reversed.

(2) (18) (15 (16) (13) -(14) (II) (1) 9 10 7 R (5) **6**) (3) (4) (1) (2) В

The figure shows the same switching position stop mechanism as in (1) with 4-point switching.

The circuit between terminals 5 and 6 shows that it is continuously closed when the switch becomes positions A and T.


The circuit between terminals 9 and 10 shows that it is closed until the switch goes from position A to the middle between positions A and T, and is opened in position T.

The circuit between terminals 11 and 12 shows that it is closed until the switch goes from position T to the middle between positions T and A, and is opened in position A. Therefore, the circuit between terminals 9 and 10 and that between terminals 11 and 12 are simultaneously closed when the switch goes to the middle between positions A and T.

4 Example of selecting a contact arrangement figure



For example, please select the right figure T6005M from the standard development figures (Page A97 to A101) when the switch with the circuit in the left figure is required. In this case, the terminal numbers should be assigned as in the standard drawing.



TECHNICAL DATA

Breaking and making current capacity


Туре		AC		DC			
		Test voltage (V)	Test current (A)	Load condition	Test voltage (V)	Test voltage (V)	Load condition
	Rotating operation type	121	8	Power factor: Pf = 0.6 to 0.7	52.8	11	Time constant: L / R = 40±6ms
M, ML			4		121	2.2	
		_	_		242	0.77	

Break / make circuit current capacity test

To conduct the break / make circuit current capacity test, connect the air-core reactor, which is connected in series to a resistor, to the switch as illustrated in Fig. 1 or 2. Using the test current specified in Table 1, perform CO 50 times for AC and 20 times for DC at intervals of 10 seconds when the voltage is 1.1 times the rated operating voltage of the switch. At this test, check for:

- (1) Short-circuit between poles or earth fault due to generated arc, or broken or burnt switch.
- (2) Any other harmful fault in use

Note: CO means performing the making action (C) and then the breaking action (O) about 50 ms later. For a switch that has some identical structures used for the same electric potential, select an adjacent contact or a contact that is most likely to lead the arc to the frame and then carry out the test using the circuit shown in Fig. 1. For a switch in which an adjacent contact is used at a different electric potential, perform the test as shown in Fig. 2.



Note: For DC, connect a parallel resistor so that 1% of the test current value flows in parallel with the loads (R-L).

Table 1

AC or DC	Class	Test voltage	Test current		Power factor (AC) or	
AC OF DC			Making	Breaking	time constant (DC L / R: ms)	
	AC11	1.1 <i>Ue</i>	11.0 le	11.0 le	0.6 to 0.7	
Alternating current (AC)	AC12	1.1 <i>Ue</i>	2.2 le	2.2 le	0.6 to 0.7	
(AO)	AC13	1.1 <i>Ue</i>	1.1 le	1.1 le	0.9 to 1.0	
	DC11	1.1 <i>Ue</i>	1.1 le	1.1 le	100 ± 15	
Direct current	DC12	1.1 <i>Ue</i>	1.1 le	1.1 <i>le</i>	40 ± 6	
(DC)	DC13	1.1 <i>Ue</i>	1.1 le	1.1 <i>le</i>	7 ± 1	
	DC14	1.1 <i>Ue</i>	1.1 le	1.1 <i>le</i>	1 or less	

Note: le shows for rated operating current and Ue shows rated operating voltage.