

#### **FEATURES**

- For connection of CT circuit, this connector can be used for input transformer and current protection relay and so on.
- ■Although it's compact, adopts contacts with high reliability and maximum current-carrying capacity of 5A is also possible. The contact pressure of the contact part is high, and the insertion load is lightly designed.
- ■The plug and socket can only be inserted in a single direction to prevent any wrong insertion by the plug stopper.

# New lineup of short bar for CTM type (for 3 pole)

- ■Applicable models: CTM / CTMH / CTMX (Socket)
- ■Only sold separately and not assembly.

#### ●CTM-SB9RCB-3



#### **SPECIFICATIONS (RATINGS, PERFORMANCE)**

Type	стм стмн стмх								
Rated insulation voltage (Ui)	250V								
Rated current-carrying capacity (lth)	5A								
Max. wire size		2mm²							
Screw size		M3.5×7							
Power-Frequency withstand voltage	(Live part to assembly mounting panel) 2,000V AC / 1 min. / (Between live parts) 2,000V AC / 1 min.								
Rated impulse withstand voltage	(Between live parts and mounting panel) ±7kV / 3 times for each pole (1.2 / 50µs) (Between live parts) ±4.5kV / 3 times for each pole (1.2 / 50µs)								
Short-time current	200A 1 sec.								
Contact resistance	Between poles 10m Ω max. (initial value)								
Shock resistance		500 m/s <sup>2</sup> (6 directions)							
Ambient operating temperature		–20 to 60°C							
Relative humidity		85% or less							
Altitude		2,000 m or less							

#### **HOW TO ORDER**

#### Plug side

CTM-S9

①Basic	type	3No. of poles (max. 12 poles)	②Plug	9
Code	Shape		Code	Shape
СТМ	Vertical angle(standard)		S	Standard plug
CTML	L-angle		J	L-angle screw terminal

Applicable to both A and V type socket.

#### Socket side

## CTM-A6V3

1)Basic	type	TT	$\neg \neg$	 3 No. of poles (max. 12	poles)	2Sock	et
Code	Shape		-	J. C.	<u> </u>	Code	Type
СТМ	Screw terminal					Α	for current
СТМН	Screw terminal with convex					٧	for voltage
СТМХ	Up-screw terminal with convex						

#### Plug and socket

### CTM-SA6SV3

①Basic	type			
Code	Sha	ipe		
СТМ	Screw terr	minal		
СТМН	Screw terminal with convex			
СТМХ	Up-screw ter	rminal with convex		

\*For details, see below.


3No. of poles


2Plug and socket

	Code	Туре
Ī	SA	for current (S plug)
Ī	sv	for voltage (S plug)
Ī	JA	for current (J plug)
ſ	J۷	for voltage (J plug)

#### **CT** circuit

Since a contactor is incorporated inside (CTM-A type), each circuit is short-circuited during removing to prevent the CT circuit from opening






Remark: The above stroke has tolerance of about 1 mm in standard value. Pay careful attention to this point for your design.

#### Differences between CTM and CTMH and CTMX

The shapes of the unit (socket side) between the CTM and CTMH types are different.

The CTMH type uses different colors to visually discriminate between the current type (A type) and the voltage type (V type).

The CTMX connector is the up-screw type which improves easy wiring.



CTM-type

V unit (Black)






A unit (Black)

V unit (Gray)



CTMH-type



the gap between the socket and panel hole.



CTMX-type

C208

#### STANDARD PRODUCTS





Common plug for A type and V type.
 (Applicable to CTM, CTMH, CTMX type)


# 7.5 5 Lt. 0.5 S. Trends pice | Proceedings pice)

Pole	2	3	4	5	6	7	8	9	10	11	12
l	32	41	50	59	68	77	86	95	104	113	122
Р	42	51	60	69	78	87	96	105	114	123	132
_	52	61	70	70	99	97	106	115	124	122	1/12

#### CTML-J No. of poles (Plug)




\* Common plug for A type and V type. (Applicable to CTM, CTMH, CTMX type)



#### CTM-Type No. of poles (Socket)











\* For a combination of the A and V types Example: CTM-SA4SV4



132 142

124 133






333	M3.5		L±0.5  unting pitch  L±0.5  E±0.5  ecc   Soci	ΦΦ ket side				A type	(Black)	V tyr	pe (Gray)
E .										124	
-	2	3	4		6		8	9	10	11	12
9	2 32				"	Ţ	_	9 95	10 104	11 113	12 122
Pole		3	4	5	6	7	8				

#### CTMH-Type No. of poles (Plug, socket)




\* For a combination of the A and V types Example: CTM-SA4SV4



#### CTMX- Type No. of poles (socket)





#### 104 113 122 131 105 114 123 132 CTMX- Type No. of poles (Plug, socket)



